
The Wayback Machine - https://web.archive.org/web/20080219123358/http://www.peppersoup.net:80/tam...

lamagotehi Square

translated v-pet instructions/

Thanks to Val of <u>Tinkerville</u> and Mary Jo of <u>http://tamagotchi.port5.com/</u> for sending in these instructions!

What follows is simply a basic translation of the documentation that comes with Pocket Sakura. For much more information on Pocket Sakura gameplay and about Sakura Taisen in general, please visit <u>Carl's Sakura Archives</u>



1	
Button Name	When to use it
(A) : A button	To select a destination or item, or to view the screen (press for several seconds).
(B) : B button	To cancel an item (return to the previous screen) or to turn off the screen (press for several seconds).
Reset button	Erase all data and start over. after you press the reset button, you will get a screen saying 'restart/continue'. To erase all data, choose 'restart'. Choosing 'continue' will cancel the reset.
G:D-pad (cross button)	To choose an item or to raise or lower a number. ←→ [©] ‡ [©] To select one of these marks
3 Start	View the Settings Screen
(1) Select	View the Data Screen



1. First, remove the battery tab.

The "colours" adjustment screen will automatically appear, followed by the "clock" screen. If the "colours" screen does not appear, please press the Reset Button.

2. Adjust the colours



Using the d-pad (up and down), adjust the colours of the screen. Choose colours that are easy for you to see. When you are satisfied with the colours, press the A button. (Pressing up will make colours darker, pressing down will make them lighter).



3. Set the date and time

Use the d-pad (up and down) to select the year, then press the A button to set it. Next, set the Month, Day, and then Hour, Minutes in the same fashion.

4. Now, let's walk



Once you have set the colours and the time, Sakura will appear on the screen. First, walk to the Teito Theatre to meet with Manager Yoneda.

*In Pocket Sakura, the "Taiteikoku Theatre" is called "Teito Theatre"

Alert! In order to save battery power, Pocket Sakura has an energy conservation function. When you aren't doing anything with the unit, the screen will automatically turn off. When you want to see the screen, press the A button for several seconds. Sakura will soon reappear.

walk with Sakura



As you walk, look in the upper right corner of the screen to see how many steps you've taken. Furthermore, as you accumulate steps, you collect points. While Sakura is



